# Low Speed Contact Adapter (For DT-2100 only)

# DT-2100-OP-CAS-L

# Instruction Manual

## Safety Requirements

Before operation, maintenance and inspection, please carefully read this instruction manual/DT-2100 manual and follow it for proper

### Regarding this product

This product is the contact adapter for low speed measurement, built specifically for the hand-held non-contact multi-functional digital tachometer "DT-2100" (sold separately).

Using this product, low speed rotations, as low as 0.10 rpm, can be measured.

#### 2 Setting

Select in the DT-2100 main body display SET\_CONTENTS menu 3. SET SYSTEM  $\rightarrow$  5. CONTACT  $\rightarrow$  4. Contact(Low)

(For additional setting procedures, please refer to the operation manual for DT-2100)



SET\_SYSTEM CONTACT 7 SET GRAPH Non Contact MEM\_GROUP Auto CONTACT Contact(Low) Select 4. Contact(Low)

Select 5. CONTACT

\* This contact adapter works with 4. Contact (Low) setting. 3. Auto setting cannot be used.

## 2. Measurement

Please perform the measurement in the same manner as standard contact adapters.

For the measurement method and precautions, please refer to the operation manual of the DT-2100.

# 3. Specifications

Item	Description
Measurement range	0.10 rpm ~ 10.00 rpm
Measurement accuracy	0.10 rpm ~ 1.00 rpm : ±0.06 rpm 1.01 rpm ~ 6.00 rpm : ±0.60 rpm 6.01 rpm ~ 10.00 rpm : ±1.00 rpm
Housing	Polycarbonate resin (Black Paint)
Weight	50g (Contact Adapter only)
Accessories	2 cone adapters 1 funnel adapter Master wheel (6"Cir.) Extension shaft

\* • Additional errors in the measurement accuracy may be caused by the measuring environment.

(hand stability, the angle to the target, etc.)

- . In the case of contact measurements, the slippage of the contact or the measurement wheel may result in additional inaccuracies.
- \* Note that applying solvents such as thinner or alcohol, etc. to the contact adapter may result in the paint peeling and/or damage to the contact adapter. Cleaned only with a clean damp cloth with water or mild detergent and water.

# 1. Preparations

Before using the low speed contact adapter, please perform the following preparatory steps.

#### (1) Installation

Attach the contact adapter to DT-2100 main body as illustrated below.



